

Two to three times
the *SPEED* of
metal lath



EXPERIENCE THE THIN BRICK REVOLUTION



EXPERIENCE THE THIN BRICK REVOLUTION



US Patent 10,106,989 B2



Email: sales@speedymason.com

Phone: 608-855-5903

BRICK LATH™

Exterior/Interior

www.speedymason.com

SPEEDYMASON

EXTERIOR INSTALLATION STEPS

1. Attach Panel



2. Back Butter or Trowel



3. Place Brick



4. Bag



5. Strike



FEATURES & BENEFITS

- 16" x 48" & 16" x 96" Panels
- 50-year panel warranty
- Hurricane test compliant
- Panel legs lay out brick coursing
- Speedymason Brick Lath is a barrier system like metal lath
- No more working with sharp metal
- Mortar mechanically bonds to Speedymason Brick Lath
- Full bed mortar system allows installer to feather out imperfections
- Panels fit Modular, Norman, King, Queen, American Imperial and Meridian size thin brick

INTERIOR INSTALLATION STEPS

1. Attach Panel



2. Spot Bond Brick



3. Place Brick



4. Bag



5. Strike



See Speedymason installation on [YouTube](#)

BRICK LATH™